

# Legend

Module

Error message

Intermediate function

Refers to same error message above

## Error code :

-XYZ

Refers to the module number (1, 2, 3, 4, 5 ou 9)

Refers to the middle level function in which the error occurred

Refers to the low level category of the error

### initialization


Check user options -X00

### Low-level related error

- Rank computation -XX1
- LU decomposition -XX2
- Cholesky decomposition -XX3
- Eigen value problem -XX4
- Number is Nan -XX7
- Error during files writing/opening -XX9

### Middle-level related error


- Module-specific errors -X10 -X19
- Related to qdd\_u -X3 X
- Related to ux\_d -X4 X
- Closing geometry -X5 X
- accelred -X6 X
- dirdynared -X7 X
- Rred matrix -X8 X
- Mred matrix -X9 X



Real-time related errors:  
-410



# Legend



## Error code :

